

Terminal diagram

1	100	Negative pole
2	200	Positive pole
3	203	Fuel
4	205	Starting
5	K14	Charger
6	K18	Oil pressure sensor
7	K17	Water Tem sensor
8	K21	Low oil pressure alarm
9	K20	High water Tem alarm
10	K15	Speed sensor
11	K16	
12	DL	Mains Supply 220VAC
13	DN	
14	A	Actuator
15	B	
16		
17		

Sign	Date	HGM6110 Schneider
		Jiangsu Starlight Electricity Equipment Co.,Ltd